

```

1  PROGRAM PLC_PRG
2  VAR
3      PID_SERVO_X      : fbdiscretePID ;
4      PID_SERVO_Y      : fbdiscretePID ;
5      PushBMoveXY_enable : BOOL ;          // PushButton
6      PushBErr_ACK     : BOOL ;          // PushButton
7      Start_XYmovement : R_TRIG ; // now in use for testing purposes, can be
// used to activate your application
8      Error_ACK        : R_TRIG ; // now in use for testing purposes, can be
// used for other activities
9      ProductOrderTable : ARRAY [ 1 .. MAX_ArrayLength ] OF DosingRecipe2 ;
10
11      PProductActive    : BOOL := FALSE ;
12
13      ServoXYState      : XYState := IDLE ; // Init state
14      getXYsetpoints    : fbGetXYCoordinates ;
15      LocationNr        : INT ;          // Obtained by the slider. See
// Vizualisation
16      SaturationWarning : BOOL ;
17      CurrentRecipeNr   : SINT := 0 ;
18      LocationBits      : BYTE ; // Bit Patterns with component locations
19      DropLocation      : SINT ; // Location to drop or deliver the
// components
20      SetLocation       : SINT ; // variable used for the moving function
21      NozzleLocation    : SINT := 1 ;
22
23      SettlingTime      : TON ; // Predetermined settling time
24      NozzleChange      : TON ; // Time neded to Nozzle change at position
// 1
25      DoseCompTime      : TON ; // Time needed to get or to drop component
26      StartSettling     : BOOL := FALSE ; // Predetermined Settling Time
// duration will start
27      StartNozzleChange : BOOL := FALSE ; // Start Nozzle Change on
// Position 1
28      StartDosing       : BOOL := FALSE ; // to get new dosage or to
// deliver the dosage
29
30      NextCompLoc       : SINT ; // Next location of Component [2..6]
31      Recipes_aval      : BOOL := FALSE ;
32      Recipe_OK         : BOOL := FALSE ;
33
34      Err_Sign          : BOOL := FALSE ; //Generic alarm
35  END_VAR
36  VAR CONSTANT
37      MAX_ArrayLength : SINT := 24 ;
38  //
39  //
40  END_VAR
41

```

```

1  // Create Recipe
2  IF NOT Recipes_aval THEN
3      CreateRecipe ( Table := ProductOrderTable ) ;
4      Recipes_aval := TRUE ;
5      Recipe_OK    := TRUE ; // Is Set for testing purposes

```

```

6      //
7      END_IF
8
9      //The below code is for PID testing purposes ONLY. comment out the state
      machine for use.
10     // IF (Start_XYmovement.Q) THEN
11     // //
12     // Recipe_OK := TRUE; // Only for testing. should be removed later
13     //     getXYsetpoints(Pos:=LocationNr, // get setpoints XY for location
      number;
14     //     XCoor=>PID_SERVO_X.Setpoint,
15     //     YCoor=>PID_SERVO_Y.Setpoint);
16     // END_IF
17
18     // Following Function Blocks should be executed every cycle
19     SettlingTime ( in := StartSettling , PT := T#2500MS );
20     NozzleChange ( in := StartNozzleChange , PT := T#3000MS ); // Nozzle Change
      Time; SEE PART 2 DOC
21     DoseCompTime ( in := StartDosing , PT := T#2000MS ); // Picking / Dropping
      Time ; SEE PART 2 DOC
22
23     //Push buttons
24     Error_ACK ( CLK := PushBErr_ACK );
25     Start_XYmovement ( CLK := PushBMoveXY_enable );
26
27     CASE ServoXYState OF
28         IDLE :           //IDLE state; no actions to be taken.
29             Err_Sign := FALSE ;
30             IF Start_XYmovement.Q OR PProductActive THEN
31                 PProductActive := TRUE ;
32                 CurrentRecipeNr := CurrentRecipeNr + 1 ;
33                 ServoXYState := CHECKING ; // Start with checking the recipe
34             END_IF
35
36         CHECKING :
37             recipe_OK := CheckRecipeNr ( ProductOrderTable [ CurrentRecipeNr ] ) ;
38
39             IF ( recipe_OK ) THEN
40                 LocationBits := ProductOrderTable [ CurrentRecipeNr ]. PosLocBits
; // Location position bits
41                 DropLocation := ProductOrderTable [ CurrentRecipeNr ].
      DeliveryLocation ; // Location for delivery
42                 StartSettling := FALSE ;
43                 NextCompLoc := NxtComp_Locnr ( LocationBits ); // Go to
      (next)component location
44                 SetLocation := NozzleLocation ;
45                 ServoXYState := MOVING ;
46                 recipe_OK := FALSE ;
47             ELSE //error; recipe not oke
48                 ServoXYState := CHECKING ;
49                 Err_Sign := TRUE ;
50                 PProductActive := FALSE ; // Production on Hold ( Stopped) due
      recipe error..
51
52                 //go to nozzle location

```

```

53         getXYsetpoints ( pos := NozzleLocation ,
54         XCoord => PID_SERVO_X . Setpoint ,
55         YCoord => PID_SERVO_Y . Setpoint ) ;
56
57         IF Error_ACK . Q THEN           //Resume production on error button
press.
58             ProductActive := TRUE ;
59             ServoXYState := IDLE ;
60         END_IF
61     END_IF
62
63     MOVING :
64         IF ( NextCompLoc <> 0 ) THEN           // Next Comp location is found;
move to designated location
65             IF ( StartSettling = FALSE ) THEN
66                 getXYsetpoints ( pos := SetLocation ,
67                 XCoord => PID_SERVO_X . Setpoint ,
68                 YCoord => PID_SERVO_Y . Setpoint ) ;
69                 StartSettling := TRUE ;
70             END_IF
71
72             IF ( SettlingTime . Q ) THEN
73                 ServoXYState := NOZZLING ;
74             END_IF
75         ELSE
76             ServoXYState := IDLE ;
77         END_IF
78
79         // Consider to merge State 2, State 3 and State 4 as one State :
"ServoMove_State" (combination of MOVING & NOZZLING states)
80     NOZZLING :
81
82         IF ( SetLocation = NozzleLocation ) THEN
83             StartNozzleChange := TRUE ;
84         ELSIF ( ( SetLocation = NextCompLoc ) OR ( SetLocation =
DropLocation ) ) THEN
85             StartDosing := TRUE ;
86         END_IF
87
88         IF NozzleChange . Q THEN
89             StartNozzleChange := FALSE ;
90             StartSettling := FALSE ;
91             SetLocation := NextCompLoc ;
92         ELSIF ( ( DoseCompTime . Q ) AND ( SetLocation <> DropLocation ) )
THEN
93             StartDosing := FALSE ;
94             StartSettling := FALSE ;
95             SetLocation := DropLocation ;
96         ELSIF DoseCompTime . Q THEN
97             StartDosing := FALSE ;
98             StartSettling := FALSE ;
99             NextCompLoc := NxtComp_Locnr ( LocationBits ) ;
100            SetLocation := NozzleLocation ;
101        END_IF
102        ServoXYState := MOVING ;
103    END_CASE ;

```

```
104
105      (*
106      // =====
107      // Executing PID controllers every cycle. Do not change or modify the source
108      // =====
109      *)
110      PID_SERVO_X . Auto_Mode := TRUE ;
111      PID_SERVO_X . Kp := 0.837600052042507 ; // tuned
112      PID_SERVO_X . Ki := 0 ; // tuned
113      PID_SERVO_X . Kd := 0.171610226044254 ; // tuned
114      PID_SERVO_X . MV_max_sat := 10 ;
115      PID_SERVO_X . MV_min_sat := - 10 ;
116      PID_SERVO_X . PrGain := 10 ;
117      PID_SERVO_X ( PprocessValue := SERVO_XPOS . Yout ,
118                    q_MV_out => SERVO_XPOS . Xin ,
119                    qx_Saturation => SaturationWarning ) ;
120
121      PID_SERVO_Y . Auto_Mode := TRUE ;
122      PID_SERVO_Y . Kp := 0.390618492352991 ; // tuned
123      PID_SERVO_Y . Ki := 0 ; // tuned
124      PID_SERVO_Y . Kd := 0.177236237453083 ; // tuned (very little overshoot from
125      pos40 to pos1)
126      PID_SERVO_Y . MV_max_sat := 10 ;
127      PID_SERVO_Y . MV_min_sat := - 10 ;
128      PID_SERVO_Y . PrGain := 10 ;
129      PID_SERVO_Y ( PprocessValue := SERVO_YPOS2 . Yout ,
130                    q_MV_out => SERVO_YPOS2 . Xin ,
131                    qx_Saturation => SaturationWarning ) ;
```